



Rear Bumper Assembly Instructions

Only for Charger, Agri-Trac and PK Diesel models

1

Unpack the rear bumper frame and remove all of the packing material. You will find all of hardware needed to install the rear bumper assy to your pedal kart already pre-attached to the frame.



2

Remove the hardware from all 3 tab locations.



3

Slide the rear bumper assembly under the brake arm until its all the way up as far as it can go.



4

Align the metal channels of the rear bumper frame onto the rear square frame of the kart and re-assemble the hardware onto all 3 tab locations until tight.